

Use your Chromebook touchpad

You can use your Chromebook's touchpad to move the pointer, right-click items on the screen, and more.



Move the pointer: Move your finger across the touchpad.



Click: Press the lower half of the touchpad. You can also tap the touchpad to click.



Right-click: Press the touchpad with two fingers. You can also press **Alt**, then click with one finger.



Scroll: Place two fingers on the touchpad and move them up and down to scroll vertically, or left and right to scroll horizontally.

Go back or forward: Quickly move two fingers left or right to go back or forward on web pages or while using apps.

See all open windows: Swipe up or down with three fingers.

Switch between tabs: If you have multiple browser tabs open, you can swipe left and right with three fingers to quickly move between tabs.



Drag and drop: With one finger, click the item you want to move. With a second finger, move the item. Release both fingers to drop the item at its new location.

